



Monteringsvejledning – dansk

- ▣ Montering i gipsvægge sker ved forstærkning af stålskinnerne ved indlæg af lægter i skinnerne, hvori elementet fastgøres.
- ▣ Elementer fra 13M fastgøres med 1-2 skruer i midten af topskinne.
- ▣ Fjern transportbræt i bunden af elementet.
- ▣ Elementet bringes i lod og vater. Derefter fastgøres karmen med 3 stk. skruer/karmdyvler i hver stolpe.
- ▣ Dørpladen skydes frem i dørhullet og justeres i topbeslag således, at den kører og lander midt i døråbningen. Ved synkrontræk monteres alu-vinkel på toppen af dørpladen 20 cm fra forkant. Luk dørpladerne således at de er samlet midt i døråbning og fastspænd wiren til alu-vinkel beslag.
- ▣ Karme er monteret på bundstyr, som fastgøres i gulvet/underlaget.
- ▣ Gipsplader fastgøres på løsholte op mod karmen og føres ud over elementet. Skruelængde ved 1 lag gips: max. 25 mm.
- ▣ VIGTIGT: Gipspladen må IKKE have en krumning ind imod element.
- ▣ Indfatninger fastgøres med dykkere max. 35 mm. NB: Indfatning ved aftagelig topliste monteres min. 10 mm fra underkant, således at listen ikke fastsømmes, men stadig kan afmonteres.
- ▣ Undgå at søm/skruer går ind i dørpladen.
- ▣ LØBEVAGNE OG SKINNE MÅ IKKE SMØRES MED OLIE ELLER ANDRE GLIDEMIDLER

Installation instruction - English

- ▣ Mounting in a drywall you need to strengthen the steel construction prior to install the Skydoor.
- ▣ Elements wider than 13M must be connected in the top with 1-2 screws.
- ▣ Remove the transport board in the bottom of the element.
- ▣ Level up the element and use 3 screws in each side of the frame.
- ▣ Push the doorplate forward and adjust the doorplate so it close in the middle of the opening. It it's a synchronous closure mount the angle brackets 20 cm from the front of the doorplate. Close the door and the connect the angle brackets to the wire.
- ▣ The door frame must be connected to the floor.
- ▣ Make sure the plasterboard is correct connected to the horizontal profiles on the element If it only one layer of plaster board the max screw length is 25 mm.
- ▣ Important: The plasterboard is now straight, make sure to mount it correct.
- ▣ The profiles around the door it connects the nails max 35 mm and be aware not to nail the top profile in a way it can't be removed.
- ▣ Avoid nail and screws hits the doorplate.

- ☞ The carrier and profile must not be lubricated with oil etc.

